

Main Pump Motor .

GENERAL INFORMATION

Disinfectant Line Pressure

Regulator

Medical Equipment Washing & Decontamination Systems

Mechanical Components Detergent Injection Pump Rear View **Rinse Injection Pump** Disinfectant Injection Valve Location (not visible in picture) Power Cord with GFCI **Priming Switch For Chemical Pumps Chemical Tray** Main Electric **Terminal Strip Pressure Sensor** Fill Line **Drain Pump** (Located behind main pump) **Drain Line Main Water Pump** Fill Valve Disinfectant Line Valve

Aqua Phase, A Division Mid-State Stainless Inc. ● 330 W. Benson Ave. ● PO Box 228 ● Grantsburg, WI 54840 ● USA 800-208-9274 ● 715-463-5851 ● FAX: 715-463-5853 ● Email: aquaphase@medwashers.com ● WEB: www.aqua-phase.com

Heavy -Duty Caster Wheels




GENERAL INFORMATION FILTERS & SCREENS

IT IS RECOMMENDED THAT YOU CHECK THE FILTERS DAILY FOR DEBRIS AND CLEAN THEM OFTEN.

Bottom Center Spray Arm

Rear Wheel Brushes



Primary Filter Screen

Located in the center of the water reservoir cover.

If this becomes clogged and prevents water from getting to the pump, the Aqua Phase will make a "Growling" noise in addition to low pressure in the spray system.


THIS SCREEN MUST BE IN PLACE AT ALL TIMES OR PUMP DAMAGE MAY OCCUR!

Reservoir

Picture of Aqua Phase Wash Chamber

Looking through the front door.

Primary Filter Screen (Removed)



Secondary Filter Screen

Located in the center of the water reservoir, under the Primary Filter Screen. Primary Filter Screen must be removed first in order to access the Secondary Filter Screen.

This screen is hinged. It can be flipped to the side for cleaning.

This screen serves as protection to the Main Water Pump.

THIS SCREEN MUST BE IN PLACE AT ALL TIMES OR PUMP DAMAGE MAY OCCUR!

Picture of Aqua Phase Wash Chamber.

Looking through the Front Door.

IF YOUR UNIT DOES NOT HAVE THE FILTER SCREENS SEATED PROPERLY, IN THEIR PLACE AT ALL TIMES, YOU CAN EXPECT THE SPRAY NOZZLES TO BECOME CLOGGED.